

FlamLINE® Torching installation

Soba®

Important

A

Preparation

- Lay out the Soba FlamLINE® waterproof expansion joint and verify its length and all detailing.
- Soba FlamLINE® can accommodate a pre installation movement of up to 2 mm per meter.
- Before installation notify supplier of any discrepancies in length or detailing.
- Lay Soba FlamLINE® with the logo side up.
- Ensure that the Soba FlamLINE® and the waterproofing substrate is completely dry before beginning installation.
- Cut the waterproofing membrane at the joint location.

B or variant **C** Torching

B Apply heat to the waterproofing ply and embed the Soba FlamLINE® into it, using the “torch and flop” technique. Press the Soba FlamLINE® into the hot waterproofing with a blunt putty knife.

C Apply heat to the waterproofing ply and unroll the Soba FlamLINE® into it. Press the Soba FlamLINE® into the hot waterproofing with a blunt putty knife.

D Flashing in

Flash in the Soba FlamLINE® with a compatible torch down flashing ply, encapsulating the Soba FlamLINE®.

- After installation provide mechanical protection for the Soba FlamLINE® waterproof expansion joint. Protection can be in the form of a protective mat or a polymer bituminous strip fixed at intermittent points.

Soba FlamLINE® is always installed by encapsulation between roofing/waterproofing membrane plies.

